

SINAV SORU VE CEVAP KAĞIDI

QUESTION and ANSWER SHEET

Dersin Kodu: Course Code: MAK540/SEY524/STS611	Dersin Adı: Course Title: MAKİNE MÜHENDİSLİĞİNDE ÖZEL KONULAR SAVUNMA SANAYİNDE OTONOM SİSTEMLER İNSANSIZ SAVUNMA SİSTEMLERİ		Dersin Şubesi: Course Section: 01
Ders Sorumlusu Öğretim		Sınav Tarihi:	Sınav Saati:
Elemanının Adı Soyadı:		Date of Exam:	Hour of Exam:
Name of Lecturer: ANDAÇ TÖRE ŞAMİLOĞLU		08/ 06/ 2023	:
Adı Soyadı:		Öğrenci Numarası:	
Name-Surname:		Student Number:	
Fakülte/MYO/YO/Enstitü:		Bölüm/Program:	
Faculty/Vocational School/Institute:		Department/Programme:	

2022-2023 Spring Semester TAKEHOME FINAL EXAM (Due to 15.06.2023)

Duration: 1 Week

PROBLEM)

Use the same stereo camera set up in Midterm Examination. You are supposed to do the following:

- 1. Run the disparity_params.py code to adjust the disparity parameter using the GUI.
- 2. The disparity to depth linear relation (obtained by LSE method) is supplied in disparity_to_depth.py code. You should modify this code to record a lookup table. Use at least 5 different distances.
- 3. The obstacle avoidance example code is given. (obstacle_avoidance.py). This code finds the objects closer than the threshold and write warning messages. Modify this code to use look-up table you recorded in 2. The new code is supposed to draw the boundaries of the first 5 closest objects on the original image captured from left camera. And also write the distance on the middle of the objects.
- 4. Record a video of the code in 3 running.
- Submit your video and code project to moodle system (oys.baskent.edu.tr)
- If the file size is over 10MB, then please provide a download link.

disparity_params.py

```
import numpy as np
CamL id = 0 # Camera ID for left camera
CamR id = 1 # Camera ID for right camera
CamL = cv2.VideoCapture(CamL id)
CamR = cv2.VideoCapture(CamR id)
cv file = cv2.FileStorage("improved params2.xml", cv2.FILE STORAGE READ)
Left Stereo Map x = cv file.getNode("Left Stereo Map x").mat()
Left Stereo Map y = cv file.getNode("Left Stereo Map y").mat()
Right Stereo Map x = cv file.getNode("Right Stereo Map x").mat()
Right Stereo Map y = cv file.getNode("Right Stereo Map y").mat()
cv file.release()
def nothing(x):
cv2.namedWindow('disp', cv2.WINDOW NORMAL)
cv2.resizeWindow('disp', 600, 600)
cv2.createTrackbar('numDisparities', 'disp', 1, 17, nothing)
cv2.createTrackbar('blockSize', 'disp', 5, 50, nothing)
cv2.createTrackbar('preFilterType', 'disp', 1, 1, nothing)
cv2.createTrackbar('preFilterSize', 'disp', 2, 25, nothing)
cv2.createTrackbar('preFilterCap', 'disp', 5, 62, nothing)
cv2.createTrackbar('textureThreshold', 'disp', 10, 100, nothing)
cv2.createTrackbar('uniquenessRatio', 'disp', 15, 100, nothing)
cv2.createTrackbar('speckleRange', 'disp', 0, 100, nothing) cv2.createTrackbar('speckleWindowSize', 'disp', 3, 25, nothing) cv2.createTrackbar('disp12MaxDiff', 'disp', 5, 25, nothing) cv2.createTrackbar('minDisparity', 'disp', 5, 25, nothing)
stereo = cv2.StereoBM create()
while True:
     if retL and retR:
                                         Left_Stereo_Map_x,
                                         Left_Stereo_Map_y,
                                         cv2.INTER LANCZOS4,
```

```
Right nice = cv2.remap(imgR gray,
                               Right Stereo Map y,
                               cv2.INTER LANCZOS4,
                               cv2.BORDER CONSTANT,
       preFilterSize = cv2.getTrackbarPos('preFilterSize', 'disp') * 2 + 5
        uniquenessRatio = cv2.getTrackbarPos('uniquenessRatio', 'disp')
        speckleRange = cv2.getTrackbarPos('speckleRange', 'disp')
        speckleWindowSize = cv2.getTrackbarPos('speckleWindowSize', 'disp')
       disp12MaxDiff = cv2.getTrackbarPos('disp12MaxDiff', _'disp')
        stereo.setNumDisparities(numDisparities)
       stereo.setPreFilterType (preFilterType)
       stereo.setPreFilterSize(preFilterSize)
       stereo.setPreFilterCap(preFilterCap)
       stereo.setUniquenessRatio(uniquenessRatio)
       stereo.setSpeckleRange(speckleRange)
       stereo.setSpeckleWindowSize(speckleWindowSize)
       stereo.setDisp12MaxDiff(disp12MaxDiff)
       stereo.setMinDisparity(minDisparity)
       disparity = stereo.compute(Left nice, Right nice)
       disparity = disparity.astype(np.float32)
       cv2.imshow("disp", disparity)
        if cv2.waitKey(1) == 27:
        CamL = cv2.VideoCapture(CamL id)
        CamR = cv2.VideoCapture(CamR id)
cv file = cv2.FileStorage("./data/depth estmation_params_py2.xml",
cv\overline{2}.FILE STORAGE WRITE)
  file.write("blockSize",blockSize)
```

```
cv_file.write("preFilterType", preFilterType)
cv_file.write("preFilterSize", preFilterSize)
cv_file.write("preFilterCap", preFilterCap)
cv_file.write("textureThreshold", textureThreshold)
cv_file.write("uniquenessRatio", uniquenessRatio)
cv_file.write("speckleRange", speckleRange)
cv_file.write("speckleWindowSize", speckleWindowSize)
cv_file.write("disp12MaxDiff", disp12MaxDiff)
cv_file.write("minDisparity", minDisparity)
cv_file.write("M", 39.075)
cv_file.release()
```

Disparity_to_depth.py

```
import matplotlib.pyplot as plt
CamL = cv2.VideoCapture(CamL id)
CamR = cv2.VideoCapture(CamR id)
cv_file = cv2.FileStorage("improved params2.xml", cv2.FILE STORAGE READ)
Left Stereo Map x = cv file.getNode("Left Stereo Map x").mat()
Left Stereo Map y = cv file.getNode("Left Stereo Map y").mat()
Right Stereo Map x = cv file.getNode("Right Stereo Map x").mat()
Right Stereo Map y = cv file.getNode("Right Stereo Map y").mat()
cv file.release()
max dist = 100  # max distance to keep the target object (in cm)
min dist = 30  # Minimum distance the stereo setup can measure (in cm)
sample delta = 15  # Distance between two sampling points (in cm)
Z = \max dist
Value pairs = []
disp map = np.zeros((600, 600, 3))
cv file = cv2.FileStorage("./data/depth estmation params pv2.xml",
cv\overline{2}.FILE STORAGE READ)
numDisparities = int(cv file.getNode("numDisparities").real())
blockSize = int(cv file.getNode("blockSize").real())
preFilterType = int(cv file.getNode("preFilterType").real())
preFilterSize = int(cv file.getNode("preFilterSize").real())
preFilterCap = int(cv file.getNode("preFilterCap").real())
textureThreshold = int(cv file.getNode("textureThreshold").real())
uniquenessRatio = int(cv file.getNode("uniquenessRatio").real())
speckleRange = int(cv file.getNode("speckleRange").real())
speckleWindowSize = int(cv file.getNode("speckleWindowSize").real())
disp12MaxDiff = int(cv file.getNode("disp12MaxDiff").real())
minDisparity = int(cv file.getNode("minDisparity").real())
M = cv_file.getNode("M").real()
cv file.release()
def mouse_click(event, x, y, flags, param):
    if event == cv2.EVENT LBUTTONDBLCLK:
            Value pairs.append([Z, disparity[y, x]])
```

```
x]))
cv2.namedWindow('disp', cv2.WINDOW_NORMAL)
cv2.setMouseCallback('disp', mouse click)
stereo = cv2.StereoBM create()
while True:
    retR, imgR = CamR.read()
retL, imgL = CamL.read()
        imgR_gray = cv2.cvtColor(imgR, cv2.COLOR_BGR2GRAY)
                               Left_Stereo Map x,
                               cv2. INTER LANCZOS4,
                                cv2.BORDER CONSTANT,
        Right nice = cv2.remap(imgR_gray,
                                cv2.INTER LANCZOS4,
                                cv2.BORDER CONSTANT,
        stereo.setNumDisparities(numDisparities)
        stereo.setBlockSize(blockSize)
        stereo.setPreFilterType(preFilterType)
        stereo.setPreFilterSize(preFilterSize)
        stereo.setPreFilterCap(preFilterCap)
        stereo.setSpeckleRange(speckleRange)
        stereo.setSpeckleWindowSize(speckleWindowSize)
        stereo.setDisp12MaxDiff(disp12MaxDiff)
        stereo.setMinDisparity(minDisparity)
        disparity = stereo.compute(Left nice, Right nice)
        disparity = disparity.astype(np.float32)
```

```
cv2.imshow("disp", disparity)
        if Z < min dist:</pre>
        CamL = cv2.VideoCapture(CamL id)
        CamR = cv2.VideoCapture(CamR id)
value pairs = np.array(Value pairs)
z = value_pairs[:, 0]
disp = value_pairs[:, 1]
disp inv = 1 / disp
fig, (ax1, ax2) = plt.subplots(1, 2, figsize=(12, 6))
ax1.plot(disp, z, 'o-')
ax1.set(xlabel='Normalized disparity value', ylabel='Depth from camera
ax1.grid()
ax2.plot(disp inv, z, 'o-')
ax2.set(xlabel='Inverse disparity value (1/disp) ', ylabel='Depth from
disparity')
ax2.grid()
plt.show()
coeff = np.vstack([disp inv, np.ones(len(disp inv))]).T
ret, sol = cv2.solve(coeff, z, flags=cv2.DECOMP QR)
M = sol[0, 0]
print("Value of M = ", M)
cv file = cv2.FileStorage("./data/depth estmation params py2.xml",
cv2.FILE STORAGE WRITE)
cv file.write("numDisparities", numDisparities)
cv file.write("blockSize", blockSize)
cv file.write("preFilterType", preFilterType)
cv_file.write("preFilterSize", preFilterSize)
cv_file.write("preFilterCap", preFilterCap)
cv file.write("textureThreshold", textureThreshold)
  file.write("speckleRange", speckleRange)
  file.write("speckleWindowSize", speckleWindowSize)
  file.write("disp12MaxDiff", disp12MaxDiff)
  file.write("minDisparity", minDisparity)
  file.write("M", M)
cv file.release()
```

Obstacle_avoidance.py

```
# These values can change depending on the system
CamL_id = 0  # Camera ID for left camera
CamR_id = 1  # Camera ID for right camera
CamL = cv2.VideoCapture(CamL id)
CamR = cv2.VideoCapture(CamR id)
cv_file = cv2.FileStorage("improved_params2.xml", cv2.FILE_STORAGE_READ)
Left Stereo Map x = cv file.getNode("Left Stereo Map x").mat()
Left Stereo Map y = cv file.getNode("Left Stereo Map y").mat()
Right Stereo Map x = cv file.getNode("Right Stereo Map x").mat()
Right Stereo Map y = cv file.getNode("Right Stereo Map y").mat()
cv file.release()
disparity = None
depth map = None
max depth = 200 \# maximum distance the setup can measure (in cm)
min depth = 30  # minimum distance the setup can measure (in cm)
depth thresh = 50.0 # Threshold for SAFE distance (in cm)
cv file = cv2.FileStorage("./data/depth estmation params py2.xml",
cv\overline{2}.FILE STORAGE READ)
numDisparities = int(cv file.getNode("numDisparities").real())
blockSize = int(cv file.getNode("blockSize").real())
preFilterType = int(cv file.getNode("preFilterType").real())
preFilterSize = int(cv file.getNode("preFilterSize").real())
preFilterCap = int(cv file.getNode("preFilterCap").real())
textureThreshold = int(cv file.getNode("textureThreshold").real())
uniquenessRatio = int(cv file.getNode("uniquenessRatio").real())
speckleRange = int(cv file.getNode("speckleRange").real())
speckleWindowSize = int(cv file.getNode("speckleWindowSize").real())
disp12MaxDiff = int(cv file.getNode("disp12MaxDiff").real())
minDisparity = int(cv file.getNode("minDisparity").real())
M = cv file.getNode("M").real()
cv file.release()
def mouse click(event, x, y, flags, param):
        print("Disparity= %.4f" % disparity[y, x])
print("Distance = %.4f cm" % depth_map[y, x])
```

```
output canvas = None
stereo = cv2.StereoBM create()
def obstacle avoid():
    mask = cv2.inRange(depth map, 10, depth thresh)
    if np.sum(mask) / 255.0 > 0.01 * mask.shape[0] * mask.shape[1]:
cv2.CHAIN APPROX SIMPLE)
        cnts = sorted(contours, key=cv2.contourArea, reverse=True)
multiple tiny regions)
        if cv2.contourArea(cnts[0]) > 0.01 * mask.shape[0] * mask.shape[1]:
            depth mean, = cv2.meanStdDev(depth map, mask=mask2)
            cv2.putText(output_canvas, "WARNING!", (x + 5, y - 40), 1, 2,
            cv2.putText(output canvas, "%.2f cm" % depth mean, (x + 5, y +
40), 1, 2, (100, 10, 25), 2, 2)
        cv2.putText(output canvas, "SAFE!", (100, 100), 1, 3, (0, 255, 0),
while True:
        output canvas = imgL.copy()
        Left nice = cv2.remap(imgL gray,
                               Left_Stereo_Map_x,
Left_Stereo_Map_y,
                               cv2. INTER LANCZOS4,
                               cv2.BORDER CONSTANT,
```

```
Right nice = cv2.remap(imgR gray,
                       cv2.INTER LANCZOS4,
                       cv2.BORDER CONSTANT,
stereo.setNumDisparities(numDisparities)
stereo.setBlockSize(blockSize)
stereo.setPreFilterType(preFilterType)
stereo.setPreFilterSize(preFilterSize)
stereo.setPreFilterCap(preFilterCap)
stereo.setTextureThreshold(textureThreshold)
stereo.setUniquenessRatio(uniquenessRatio)
stereo.setSpeckleRange(speckleRange)
stereo.setSpeckleWindowSize(speckleWindowSize)
stereo.setDisp12MaxDiff(disp12MaxDiff)
stereo.setMinDisparity(minDisparity)
disparity = disparity.astype(np.float32)
disparity = (disparity / 16.0 - minDisparity) / numDisparities
depth map = M / (disparity) # for depth in (cm)
mask temp = cv2.inRange(depth map, min depth, max depth)
depth map = cv2.bitwise and(depth map, depth map, mask=mask temp)
cv2.imshow("disp", disparity)
if cv2.waitKey(1) == 27:
CamL = cv2.VideoCapture(CamL id)
CamR = cv2.VideoCapture(CamR id)
```